How to upgrade TP-LINK Wireless Access Point

Notice:

- **Please verify the hardware version of your device for the firmware version. Wrong firmware upgrading may damage your device and void thewarranty.**


- **After you downloaded the firmware from TP-LINK website, please use decompression software such as WinZIP or WinRAR to extract the firmware file to a folder;**

- **It's recommended to upgrade the firmware via cable connection;**

- **Do NOT turn off the power or cut down the Ethernet cable during upgrade process;**

- **Because after upgrading the old settings may be lost, so please write down the key settings as a backup before you start to upgrade.**

Step 1 Log into the TP-LINK device by typing http://tplinkap.net/ in the address bar of the web browser (such as Internet Explorer, Firefox). The username and password are both **admin** unless you have changed it before.

Step 2 Click **System Tools** ->**Firmware Upgrade**, click the **Browse** button to choose the firmware you already extracted in the folder.

Step 3 Click the **Upgrade** button. The device will reboot automatically after the upgrading has been finished. Please wait about 3 minutes.

Step 4 Click **Status**, verify that the device's firmware has been upgraded.

Step 5 Then, check the status page of your device, if necessary please re-enter or reconfigure the device manually with the parameters you have written down before upgrading.