

Quick Installation Guide

150Mbps High Gain Wireless USB Adapter

MODEL NO. TL-WN722N / TL-WN722NC

7106505109 REV7.0.0




For more information, please visit our website: <http://www.tp-link.com>




1 Connect to a Computer

Option 1: Directly



Option 2: Via the USB Extension Cable




Note: In Windows XP, a Found New Hardware Wizard window will appear when the adapter is detected. Please click **Cancel**.

2 Install Driver and Utility


You can also download the driver and utility at www.tp-link.com/

A: Insert the CD and run the **Autorun.exe** from the pop-up Autoplay window.



Note: In some operating systems, the CD screen will pop up automatically. Otherwise, run the CD manually.

B: Select TL-WN722N and click **Install Driver and Utility**, then follow the InstallShield Wizard to complete the installation.





3 Join a Wireless Network

For Windows 8.1, TP-LINK Utility is not supported, please use the Windows built-in Wireless Utility to join a network.

Option 1: Via TP-LINK Utility


Select your preferred wireless network from the pop-up utility window and click **Connect**. The symbol  indicates a successful connection.



Option 2: Via Wi-Fi Protected Setup (WPS)

A: Press the WPS button on your router.

B: Within 2 minutes, press and hold the WPS button on the adapter until the following screen appears.



C: When you are prompted "Successfully connected to the network by WPS!", click **OK**.

Option 3: Via Windows Wireless Utility

With the TP-LINK Utility closed, you can use the Windows built-in Wireless Utility to join a wireless network.